

GOLF COVER



FIELD OF APPLICATION

The cover is used to wrap the metallic apron and avoid clothes from becoming dirty when they come into contact with stainless steel. The GOLF cover resists to standard cleaning products.

CLEANING CONDITIONS

Cleaning : wash and brush the cover in hot soapy water (30°C) or in a mixture of water and a gentle detergent. **Rinsing :** with water. Do not use toxic products to clean or rinse the cover. **Storage :** After cleaning, store in a dark, dry, well-ventilated place. The cover must be replaced when it shows signs of wear and tear.

With a proper use and care, your equipment will last longer !

MATERIAL

Vinyl both sides coated on polyester support

FEATURES

- Colour : white
- Thickness : 300 µm (± 10%)
- Weight : 325 g/m² (± 10%)
- Standard dimensions (width x height in cm) : 60 x 75

NORMS AND REGULATIONS

Cover in accordance with **Article 33 of the REACH Regulation N°1907/2006** on products containing SVHC and its amendments. Does not contain silicone (and silicone derivatives), or bisphenols.